

# **Swivel Control System**

## **User Manual**

### **Version: 17-inch**

(Applicable to SMC5008, SMC5004, and SMC50C Series)

# Table of Contents

Chapter 1 Operation Interface.....	3
1 Programming Page .....	3
1 File name.....	3
2 Speed.....	3
3 Prod speed.....	4
4 Product.....	4
5 Cylinder Status Bar .....	4
6 TST PRP.....	4
7 Remainder time .....	4
8 Completed cnt.....	4
9 Product Clear.....	4
10 Operation Button Area .....	4
11 Cylinder Manual Operation Buttons .....	5
12 Operation Area Page Navigation .....	5
13 Programming Table.....	6
14 Status bar .....	6
15 Bottom menu bar.....	6
2 Program Directory Page.....	7
3 Parameter Setting Page .....	8
4 System Upgrade Page.....	11
5 System Parameter Page 1 - Encoder Parameters.....	12
Chapter 2 Instruction Description and Examples .....	13
Comprehensive Example .....	13
Chapter 4 Electrical Connections.....	15
1 Electrical Connection Instructions.....	15
2 SMC.....	16
3 Probe.....	19
4 Wire Feeder.....	20
5 Handwheel Expansion Board Wiring.....	21
6 Keypad Layout of Handwheel.....	23



while a lower value results in a slower production speed.

- 3 Prod speed
  - Displays the production capacity per minute (PPM) during automatic operation of the equipment. The PPM is calculated based on an average, so slight fluctuations in the displayed PPM during production are normal.
- 4 Product
  - Sets the total quantity of products to be produced during automatic operation. When the production count reaches the set quantity, the equipment will stop and an alarm will be triggered. This alarm can be cleared by resetting the completed quantity to zero and then pressing the Reset or Stop button, or by directly restarting the system. If the total quantity is set to 0, the equipment will continuously produce without a limit.
- 5 Cylinder Status Bar
  - Used to display the on/off status of cylinders. -1 to -4 represent the waiting states for signals 1 to 4, commonly used for interlocking with other mechanical equipment. On: Displayed in green. Off: Displayed in gray.
- 6 TST PRP
  - Displays the current speed value of the knob when in Test Mode. In Test Mode, if the knob is at the 0 position, the handwheel can be rotated clockwise to control the operating speed of the equipment, often used to verify the correctness of the program.
- 7 Remainder time
  - Displays the remaining time required to complete the preset production quantity. The number on the left represents hours, and the number on the right represents minutes.
- 8 Completed cnt
  - Displays the quantity of products that have been produced. When the completed quantity is greater than or equal to the preset quantity, the system will generate an alarm. This alarm can be cleared by resetting the completed quantity to zero and pressing the Reset button.
- 9 Product Clear
  - Clears the completed production quantity. Clearing during operation is invalid; please perform the clearing operation when the machine is `not` running.
- 10 Operation Button Area
  - **Note: The letter on the far right of the button serves as the shortcut key for this function.**
  - Reset F1: When the current system generates an alarm, pressing this button will clear the alarm after the triggering conditions have been resolved.
  - Home F2: This initiates the homing sequence for all axes. Pressing this button will bring up the homing dialog box.
  - Y Clear F3: After pressing the button, the Y-axis coordinate of the wire feeder will be reset to zero.
  - Stop F4: When pressed in automatic operation mode, the system will transition to the stop state after completing the current product. When

pressed in homing or handwheel mode, the system will immediately switch to the stop state.


- Test F5: Runs the program in test mode. This is used to verify the program's correctness and allows for real-time control of the processing speed via the adjustment knob. When the knob speed ratio is set to 0, the processing speed can be controlled by rotating the handwheel.
- Single F6: Pressing this button will cause the equipment to stop after producing one product.
- Run F7: After pressing this button, and if there are no alarms, the equipment will enter automatic production mode. Please ensure the external environment is safe before starting the equipment.
- Cut F8: Pressing this button will bring up the wire cutting dialog box. Then, pressing the space bar will execute the wire cutting action.
- In the dialog box, you can set parameters such as cutter position, wire feeding length, and speed. If the system is in handwheel mode before cutting, the wire feeding action will be skipped, and the cutting action will be executed directly.
- Ins row F9: Inserts a blank line at the current cursor position.
- Del row F10: Deletes the row data in the table selected by the cursor.
- Auto add F11: Enabling this button will activate the cumulative operation for the programming table.
- Clear (Del): Clears the data in the cell selected by the cursor.

#### 11 Cylinder Manual Operation Buttons

Manually open or close the cylinders. Operating the cylinders in automatic operation mode has no effect.

#### 12 Operation Area Page Navigation

Press the page navigation buttons to view more operation buttons. As shown below:



- **Ratio(N):** Pressing this button will magnify the distance the axis moves per handwheel increment according to the system's set magnification ratio.
- **Robot:** Manually turns the robot start signal on or off.
- **Teach F12:** Pressing this button inputs the current axis coordinates into the specified cell.
- **MPG (M):** Pressing this button switches the system to MPG mode, allowing you to switch between MPG Y ~ MPG U states by moving the cursor in the table. This operation is invalid in automatic operation mode.
- **Light:** Turns the equipment lighting on or off.
- **Del all(G):** Clears all data in the table. Exercise caution as this action is

irreversible.

- **Touch key:** Opens the virtual touch keyboard.
- **Air \*:** Manually opens or closes cylinders 7 and 8. Operating the cylinders in automatic operation mode has no effect.

### 13 Programming Table

Used for programming the product production process.

- **No.**  
The current program line number. If it is empty, it indicates that the current line of the program is invalid.
- **Y\X\A\B\C\U**  
The target coordinate positions for each axis to move to.
- **13.3 Ratio**  
Sets the running speed for a single line. If this item is not set, the program will run at the set speed for the current part number.
- **13.4 Probe**  
Sets the probe number to be detected for the current line.
- **13.5 Air**  
Controls the opening or closing of a specified cylinder. A positive number opens the cylinder, and a negative number closes it.
- **13.6 Delay**  
The pause time after the execution of the current line of the program, in units of 0.001 seconds.
- **13.7 Loop**  
Enter 1 to indicate the start of a loop; enter the number of loop repetitions in the "Repetitions" column of the same row.  
Enter 9 to indicate the end of a loop.
- **13.8 Times**  
Sets the number of repetitions for the loop execution, effective when in the same row as the loop start command (1).
- **13.9 Notes**  
Commonly used to mark the function of this section of the program for better readability. You can freely enter values from 0 to 999.  
**Note: Special values -1 to -4 indicate waiting for input signals 1 to 4 on this line.**
- **13.10 Scroll bar**  
You can click on the top, middle, or bottom of the scroll bar to control the table to page up, page down, or scroll down by one line (+1) respectively.

### 14 Status bar

- When the system generates an alarm, this is used to display the specific alarm information and date information.
- Displays the current operating status of the equipment, such as MPG, Start, Test, Homing, etc.


### 15 Bottom menu bar

- **Description from left to right**

- Program\ File\ Parameter\ IO\ Alarm history\ Remote\ Service\ Login

## 2 Program Directory Page

The file storage page displays the program file names, file numbers, and the status of the corresponding files currently stored in the system. You can perform operations such as reading, saving, and deleting selected files. When there are many files, you can use the scroll bar to browse. The file storage page is shown in Figure 3-2.



### Figure 3-2 File Storage Page

- A total of 2000 files can be stored.
- You can click the scroll bar at the top or bottom to page up or down, or use the up and down arrow keys to move the cursor and navigate through pages.
- No.: Displays the file number.
- File Name: The file identifier for the data saved by the user.
- Status: The current file status. “OK” indicates that the stored data is valid, while a blank space indicates that there is no valid data.
- To read a file, first select the file you want to read, and then press the “Read” button.

- To save a file, first select the file you want to save to, and then press the “Save” button.
- To delete a file, first select the file you want to delete, and then press the “Delete” button.
- Import/Export: This function is used to import and export files (via USB drive). Clicking it will take you to the system upgrade page where you can perform the specific operations.

### 3 Parameter Setting Page

The parameter page provides configuration areas for some commonly used working parameters, making it convenient for users to perform relevant configurations during production, and thus better complete production tasks. As shown in Figure 3-3.

Parameter Setting

Product information

Product	0000000000	piece
Completed cnt Clear(Z)	0000000000	piece
Remainder cnt	0000000000	piece
Remainder hous	0000000000	h
Remainder min	000	min
Product speed	0000000.00	p/m
Percentage completed	0000000.00	%

Product information

Speed	0000	%
File(0~1999)	0000	
Retract speed	0000	%
Probe cnt	0000	
Failed cnt Clear(X)	0000	
Probe accuracy	0000	

Wire frame parameters

Broken dly [0 is invalid]	000000000.0	s
Winding dly [0 is invalid]	000000000.0	s
Feed speed	0000	%
High speed	0000	%
Dirver length	00000	mm
	Wire drive	

Other para

Alarm output duration	000000000.0	min
Alarm output interval	0000.0	s
Robot time [0 is invalid]	0000	s
Screen active time	0000000000	min
Screensaver	After-sales	

Other para

Safety door detection	Off	
Safety Signal logic	NO	
Broken signal logic	NC	
Sec Door	SecDoor1	

Air detection

BW

Upgrade

Sys para

Touch key

Program

File

Parameter

IO

Alarm history

Remote

Service

Login

Figure 3-3 Parameter Page

#### Product information:

- Product: The total number of workpieces to be produced.
- Completed cnt: The number of workpieces that have been produced.
- Remainder cnt: The remaining number of unprocessed workpieces.



- Remainder hous: The remaining production processing hours.
- Remainder min: The remaining production processing minutes.
- Product speed: The equipment's production output per minute.
- Percentage completed: The percentage of the total planned production that has been completed.

**Product information:**

- Speed: The processing speed of the equipment.
- File(0~1999): The program number for product processing, ranging from 0 to 1999.
- Retract speed: The speed at which the tool device retracts.
- Probe cnt: The maximum number of allowed probe failures.
- Failed cnt: The count of probe failures that have already occurred.
- Probe accuracy: Sets the sensitivity of the probe signal. 1~8, the smaller the value, the faster the response.

**Wire frame parameters:**

- Broken dly: When the Break line signal duration exceeds this parameter, a Break line fault alarm will be triggered. Setting to 0 disables this function.
- Winding dly: When the Break line duration exceeds this parameter, a Break line fault alarm will be triggered. Setting to 0 disables this function.
- Feed speed: During automatic operation, the rotation speed of the wire pay-off rack.
- High speed: The speed at which the wire pay-off rack rotates when the wire pay-off lever is pulled up.
- Drive length: The wire pay-off rack will only rotate when the length of the wire feeding Y-axis exceeds this set value. Setting it to 0 disables this function.
- Wire drive: Enables or disables the wire pay-off rack control function.

**Other para:**

- Alarm output duration: The duration for which the alarm output signal is maintained. The output is automatically turned off when the set time is reached.
- Alarm output interval: The time interval between the on and off states of the alarm output signal. Setting it to 0 disables it.
- Robot time: Maximum waiting time for the robot to complete the signal; if the signal is not received within the set time, an alarm will be triggered.
- Screen active time: The time after which the screen automatically enters sleep mode or displays the screensaver when there is no operation.
- Screensaver: The options available are "After-sales" and "Alarm".

- Safety door detection: Enables or disables the safety door detection function.
- Safety Signal logic: Selects the type of safety door anomaly signal: Normally Open (NO) or Normally Closed (NC).
- Broken signal logic: The options available are “Security Gate 1” and “Security gates 1 and 2”; regardless of the selection, ensure that the corresponding points are configured in the I/O page.
- Number of security doors: Selects the type of broken-wire fault signal: Normally Open (NO) or Normally Closed (NC).
- BW: Enters the Bus Parameter Settings page.
- Upgrade: Enters the System Update page.
- Sys para: Enters the System Parameter Settings page. Login with “Machine Builder” privileges or higher is required for operation.
- Touch key: Enables or disables the virtual touch keyboard.

**Air detection:** After clicking, the following window will pop up, allowing for the testing of each cylinder's advance and retract confirmation. When testing is enabled, a time limit must be set; exceeding this limit will trigger an alarm and machine halt.

X					
Air 1 Detec on open	Air 2 Detec on open	Air 3 Detec on open	Air 4 Detec on open	Air 5 Detec on open	Air 6 Detec on open
Air 1 Detec when off	Air 2 Detec when off	Air 3 Detec when off	Air 4 Detec when off	Air 5 Detec when off	Air 6 Detec when off
Air 7 Detec on open	Air 8 Detec on open	Air 9 Detec on open	Air 10 Detec on open		
Air 7 Detec when off	Air 8 Detec when off	Air 9 Detec when off	Air 10 Detec when off	Time limit 0000.0 s	

## 4 System Upgrade Page

The system upgrade page is mainly provided for system maintenance personnel, after-sales/software engineers to upgrade the system. To use it, you need to insert a USB drive and place the corresponding upgrade file or parameter file in the root directory of the USB drive... The system upgrade page is shown in Figure 3-4.

System upgrade

Load 1

Load 2

Load 3

Load 4

Load 5

Load 6

Search Graphic Files

Search System Files

File export

File import

0 Page

Export number 0000

File size 0000000

Loaded 000000

File num 00000

File type HMI file

System para export

System para import

Machine message

Startup time: 00000 h 00 m

Production time: 00000 h 00 m

Debugging time: 00000 h 00 m

HMI version

IMG Ver	0000	/	00	/	00	00	:	00	:	00
DRW Ver	0000	/	00	/	00	00	:	00	:	00
USR Ver	0000	/	00	/	00	00	:	00	:	00
LIB Ver	0000	/	00	/	00	00	:	00	:	00
CSR Ver	0000	/	00	/	00	00	:	00	:	00
FNT Ver	0000		00		00	00	:	00	:	00

Controller version

BIO Ver	0000	/	00	/	00	00	:	00	:	00
IMG Ver	0000	/	00	/	00	00	:	00	:	00
FPG Ver	0000	/	00	/	00	00	:	00	:	00
LAD Ver	0000	/	00	/	00	00	:	00	:	00
SMC500x 转头机_17寸屏	Customer number: 000000									

Time zone 中国-北京

Time zone 000000

Chinese

Communication mode RS485

Return

Figure 3-4 System Upgrade Page

- Search Graphic Files: This button is used to search for display upgrade files.
- Search System Files: This button is used to search for host upgrade files.
- File import/export: Imports mold parameters from a USB drive to the system, or exports mold parameters to a USB drive.
- System para import/export: Imports system parameters from a USB drive to the system, or exports system parameters to a USB drive.
- Load:\* After the search is completed, clicking the Load button will load the corresponding file.

## 5 System Parameter Page 1 - Encoder Parameters

Encoder para					
Encoder function	None ▼	Encoder counting direction	Backward	Deviation threshold	00.00 mm (Set to 0 to not check)
Encoder input port	Servo 1 ▼	Use encoder to increase feed lines	000.00	Encoder count:	+0000000
Encoder resolution	00000	Check speed	0000	Encode position:	+00000.00
The length of the encoder turn	000.00 mm	Check advance	0000 %	Encoder Clr	

**Figure 3-5 Encoder Parameters**

- Encoder function: This option has two states: Enabled and Disabled.
- Encoder input port: This option has 8 servo ports to choose from.
- Encoder resolution: Fill in according to the actual resolution of the encoder.
- The length of the encoder turn: Fill in according to the physical distance corresponding to one revolution of the encoder.
- Encoder counting direction: Select the counting direction corresponding to the encoder.
- Use encoder to increase feed lines: Total wire feeding length = encoder-based wire feeding + programming table wire feeding. When the total wire feeding is completed, if the feedback length has not reached the target, an alarm will be triggered. If the feedback length reaches the target length before the wire feeding is completed, the wire feeding will stop immediately. The essential purpose of the additional wire feeding is to ensure that the wire feeding distance is sufficiently long, and this parameter should be set much larger than the machine error.
- Check speed: The speed of the axis after it moves to the “Check Advance” position.
- Check advance: The position that triggers the “Check Speed” function.
- Deviation threshold: The maximum allowed deviation. If this threshold is exceeded, an alarm will be triggered, and the machine will stop. Setting it to 0 disables the check.
- Encoder count: Pulse count.
- Encode position: The current physical position of the encoder.
- Encoder Clr: Resets the encoder count to 0.

## Chapter 2 Instruction Description and Examples

In this chapter, we will learn about all the instructions involved in this system and understand how to use the programming table.

Note that the programming in this example tutorial may differ from actual production programming. We are here only to understand how to use the programming table.

### Comprehensive Example

N	Y	X	A	B	C	U	Ratio	Probe	Air	Delay	Loop	Times	Notes
0	100												
1		5.00	20.00				50		2	3	1	5	
2	50.00	15.00	50.00										
3	10		0						-2		9		
4													

#### Explanation of Table Name:

- The leftmost side of the table is the line number. The programming table executes sequentially, starting from line 0.
- Y, X, A, B, and C represent the axes.
- Ratio: The running speed of the current line. If not set, it will run according to the "Speed" setting on the parameter setting page.
- Probe: The probe number used in the current line.
- Air: The cylinder number used in the current line. A positive number opens the cylinder, and a negative number closes it.
- Delay: The waiting time after the current line finishes before executing the next line.
- Loop: When using a loop, the loop column needs to be set to 1 and 9. Setting it to 1 indicates the starting line of the loop, and setting it to 9 indicates the ending line of the loop.
- Times: The repetitions column represents the number of loop repetitions.
- Notes: The signal used in the current line: -1 to -4 for external signals, 21 for the robot signal.

#### Table Operation Instructions:

- Line 0: The Y-axis moves to the position of 100.
- Line 1: The axes in this line move at a speed of 50%. The X-axis moves to

the position of 5, while the A-axis moves to the position of 20; cylinder 2 is opened; a delay of 3 seconds is set before executing the next line; the loop start flag 1 and the number of repetitions 5 are set.

- Line 2: The Y-axis moves another 50, while the X and A axes move 15 and 50 respectively.
- Line 3: The Y-axis moves another 10, and the A-axis returns to the origin; cylinder 2 is closed; the loop end flag 9 is set.
- End of operation.

## Chapter 4 Electrical Connections

### 1 Electrical Connection Instructions

The electrical connections primarily consist of three parts: the main controller, the wire feeder, and the handwheel.


The servo wiring sequence is explained as follows:

SMC5008		SMC5004
AXIS 1: Y	AXIS 5: C	AXIS 1: Y
AXIS 2: X	AXIS 6: U	AXIS 2: X
AXIS 3: A	AXIS 7:	AXIS 3: A
AXIS 4: B	AXIS 8:	AXIS 4: B


SMC50C
AXIS 1: Y
AXIS 2: X


Note: The SMC50C is a bus version; the default settings are as shown in the table above. To modify these settings, navigate to System Page 2 and configure the “Pulse Port” numbers.

## 2 SMC











3 Probe





## 4 Wire Feeder

When using the wire feeder's integrated controls, ensure proper wiring. Specifically, connect the Compensation Wire (X13) to 0V, connect the Broken-Wire Fault (X14) to the chassis, and also connect the 0V of the switching power supply to the chassis.



5 Handwheel Expansion Board Wiring





## 6 Keypad Layout of Handwheel

		倍率 MFO	教导 Teach
Y	X	A	B
C	U	V	
剪断 CUT	测试 TEST	▲	确认 ENTER
送线清零 Y CLR	◀	▼	▶

Note: Double-click the CUT button to execute the cutting operation.